



Titan Pro Log Splitter Ram Stop Assembly Instructions

The Ram stop kit is easily retro fitted in only 10 Minutes and will save you hours in splitting time.

The guide bars simply fit between the existing wings of your machine.

1. Unpack your Ram Stop Kit carefully and lay out on a clean flat surface, you will also require a 5mm Allen key (Not Supplied) .



2. Start with one side first, remove the front bolt of the side wing as shown in photo below and discard bolt (you will use new bolts and washers supplied)



3. Remove the back bolt from side wing and center bolt.(you will use new bolts and washers supplied)



4. Install horizontal rails between the side wing and the body of the machine. Use all **new** bolts and washers supplied



5. Ram Stop Rails in situ showing slot close to the log pusher , stopper plate is installed in this photograph



Titan Pro Ltd

Ram Stop Installed below... Now you are ready to start saving time!



Titan Pro Ltd

All photographs are the copyright of Titan Pro Ltd and all graphic design on this Manual are the copyright of Titan Pro Ltd. The copyright in all content included in this manual such as photographs, illustrations, text, is owned by either us or our content providers. No reproduction of anything in this manual is licensed without the written consent of Titan Pro, as protected by "The copyright Designs and Patents act 1988"